

## **PTM PLATFORM SET-UP**

Thank you for purchasing your Adam Equipment PTM Platform.

To unpack and set-up the PTM Platform follow these steps:

- 1) Remove the platform from the packaging. This requires 2 people to lift it out of the packaging. Use the handles to lift it out.
- 2) Place the platform on a level surface, ensuring that there is no debris or rubbish underneath as it can affect the weighing result.
- 3) Make sure there is enough clearance at either end where the ramps are so that it is not touching the floor.
- 4) Plug the cable into the platform and the weighing indicator making sure the cable is not trapped or pinched and is not causing a trip hazard.
- 5) Follow the indicator instructions to continue set-up.