



The GC is a fully featured counting indicator that offers a numeric keypad for unit weight and sample entry. A large backlit display shows unit weight, total weight and number of pieces. For check counting applications, GC offers the ability to warn the user when a predefined count has been reached. Solid ABS plastic housing is durable and easy to clean, while the wall mounting bracket provides versatility. GC operates with a mains power cord or internal rechargeable battery, so it works in locations where electricity is unavailable.

## Fundamental weighing and counting in a multi-functional indicator



### Features

- Backlit LCD shows weight, unit weight and count in one convenient location
- Colour-coded keys facilitate quick recognition of the most frequently used buttons
- Lightweight design simplifies transport and portability
- RS-232 interface is available to provide speedy connection to computers and printers
- Solid ABS housing is durable for industrial use
- Wall-mount bracket for placing indicator on vertical surface
- Audible overload alarm warns when capacity is exceeded
- Internal counting resolution 1:600,000 for precise results
- Parts counting with freely selectable sample sizes
- Parts counting optimisation automatically refines piece weight as parts are added
- Preset tare function speeds the process of repetitive weighing
- Printouts include date and time for data tracking within Good Laboratory Practices (GLP) guidelines
- Selectable digital filtering helps minimise effects of vibration and disturbances
- Zero-tracking feature ensures display returns to zero reading
- User can program alarm to sound when preset total is reached
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy

### Applications

- Weighing
- Parts counting
- Check counting

### About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

| Model                         | GC   |
|-------------------------------|--|
| Capacity Range                | Selectable                                 |
| Resolution                    | 1:80,000                                   |
| Loadcell [Excitation Voltage] | 5VDC                                       |
| Loadcells [num]               | 4 x 350ohm                                 |
| Sensitivity                   | 0.15uv/d                                   |
| Zero Range                    | 0-10mv                                     |
| Signal Range                  | 0-40mv                                     |
| Weighing Units                | g, kg                                      |
| Stabilisation Time (sec)      | 2  |
| Interface                     | RS-232                                     |
| Calibration                   | External calibration                       |
| Display                       | Backlit LCD with 20mm-high digits          |
| Power Supply                  | Power Cord / Internal rechargeable battery |
| Operating Temperature         | -10° to 40°C                               |
| Housing                       | ABS plastic                                |
| Overall Dim.                  | 260x170x115mm (wxdxh)                      |
| Net Weight                    | 2kg  |

## Accessories

| Item number     | Description   |
|-----------------|---|
| 3052010526..... | In-use cover  |
| 305200001.....  | In-use cover (pack of 5)                                      |
| 305200002.....  | In-use cover (pack of 10)                                     |
| 1120011156..... | ATP thermal printer   |
| 3126011263..... | ATP thermal printer paper                                     |
| 3126011281..... | ATP thermal printer paper (pack of 10)                        |
| 3074010266..... | RS-232 cable (Null Modem) (null-modem)                        |
| 3074010507..... | RS-232 to USB adapter (must order corresponding RS-232 cable) |
| 600002028.....  | Adam DU data collection program                               |

## Key Accessories



**ATP thermal printer**  
Easy-to-use features combined with quick set-up equals a truly versatile thermal printer. A single push-button feed key and three easy-to-read LED indicators make operation simple.



**In-use cover**  
In-use covers provide an easy and affordable way to help keep the balance clean and protected.

Supplied by