

GK Mplus Indicator



The OIML-approved GK Mplus indicator with hardened electronics offers a range of features to help improve efficiency and productivity in any harsh industrial or commercial warehouse environment yet provides the operator with a simple user interface, allowing operations such as packaging, stock taking and the shipment of goods to be completed with ease.

Adam's GK Mplus is highly accurate and can be verified up to 6000 divisions, this combined with a large backlit LCD that changes colour in checkweighing mode to quickly notify the user of pre-set limits increases not only visibility but productivity. With the addition of a full numeric keypad, the GK Mplus achieves counting applications with the same indicator, making the GK Mplus a versatile and flexible choice when used in combination with any Adam bench and/or floor scale.

Please note that GK Mplus indicators are only legal-for-trade when paired with an approved base containing a single load cell.

Robust yet versatile to accomplish weighing and counting tasks with ease

Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Backlit display changes color for quick notification of checkweighing limits
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- RS-232 interface is available to provide speedy connection to computers and printers
- Solid ABS housing is durable for industrial use
- Splash-proof housing, keypad and display are easy to clean
- Wall-mount bracket for placing indicator on vertical surface
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy
- External calibration allows for verification and adjustment with weights
- Parts counting with freely selectable sample sizes
- Parts counting optimization automatically refines piece weight as parts are added
- Preset tare function speeds the process of repetitive weighing
- Programmable capacity and readability for a variety of applications
- Quick and easy configuration using the keypad
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects
- Zero-tracking feature ensures display returns to zero reading
- Optional USB interface simplifies data communication
- Capacity tracker built into display for easily monitoring possible overloads

Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Check counting
- Dynamic / animal weighing
- Net total weighing
- Display hold

About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

GK Mplus Indicator

Model	GK-Mplus
Maximum Capacity	Selectable
Weighing units	g, kg
Stabilization time (sec)	2
Calibration	External calibration
Display	Backlit LCD with 25mm-high digits
Power supply	Internal rechargeable battery

Accessories

Item Number	Description
3052010526	In-use cover
305200001	In-use cover (pack of 5)
305200002	In-use cover (pack of 10)
1120011156	ATP thermal printer
1120014641	AIP impact printer
3074010266	RS-232 cable
3074010507	RS-232 to USB adapter
600002028	AdamDU Data Collection Program
2050013351	Indicator stand
3051410045	Wall bracket

Key Accessories



ATP Thermal Printer

Easy-to-use features combined with quick setup equals a truly versatile thermal printer. A single push button feed key and three easy-to-read LED indicators make operation simple.



AIP Impact Printer

Easy to use, the AIP high-speed dot matrix printer connects with any device containing an RS-232 or USB interface. Communication is smooth and fast, as the AIP automatically detects a scale's settings. AIP features durable ABS plastic construction and is simple to use, as it operates with just an on/off switch and a paper feed button.

Supplied By: